



ARTALO



Touch
Clock Panel

User Manual

Touch Clock Panel

TECHNICAL CHARACTERISTICS

- Displays the current time.

SPECIFICATIONS

Placement: Right or left bottom part of the mirror

Dimensions: 4.8 x 1.5 cm

TOUCH CLOCK CONTROL

1. When the mirror is connected to the power supply, the touch clock button will be backlit.
2. To set the correct time, hold the button until it starts blinking. Once the button starts blinking, you will enter the time setting mode.
3. In the first step, set the hour format (12/24) by a simple press. After selecting the hour format, leave the button in the idle phase. The clock will automatically switch to hour setting mode. After setting the hour, leave the button idle for a few seconds, and the setting will automatically switch to minute setting mode.
4. After setting the time, leave the button idle, and the changes will be saved.

Thank you for
choosing
our product.



Artalo design s.r.o.

Lískovec 393

738 01 Frýdek-Místek

Czech Republic

CIN: 10888560, TIN: CZ10888560

E-mail: info@artalo.com

www.artalo.com